

# 7476 - INSTRUCTIONS FOR R-CLIP & WASHER POSITION FOR API700 COUPLERS

1. POSITON WASHER BETWEEN R-CLIP & BUSH.
2. R-CLIP MUST BE IN THE CORRECT WAY AS SHOWN.
3. CAM PLATES MUST LINE UP WITH GROOVES IN BODY.

